

Starter Solenoid Relay Drawing

*Note: This drawing is for a grounded solenoid relay.

If using insulated ground solenoid relay "I or R" terminal will need to be grounded.

